Alarm AL 07

The AL 07 - THERMAL CUT-OFF alarm appears on KLOVER pellet stoves if your stove overheats or if the firebox door has been left open.

Solution

1. Unscrew the black cap located at the back of the stove (next to the electrical connection cable). For flat models, it is located at the bottom front of the stove
2. Press down on the white rod that pops out. You should hear a “click.”
3. If you do not hear a click, the alarm is triggered by the sensor that detects whether the firebox door or the pellet hopper door is closed. Check that when closing both doors, the push button makes proper contact and you hear a click.
4. Hold down the ignition button on the remote control until the text “Final Cleaning” appears
5. Wait about 10 minutes for the stove to complete its cleaning cycle
6. As soon as “Off” appears on the remote control, you can restart the stove