

The alarm AL 08 - NO DEPRESS appears on the KLOVER pellet stoves if the draught in the flue is insufficient or if the pellet reservoir door has been left open.

## Resolution

1. Check that the pellet hatch is closed properly (a `data-toggle=tooltip data-placement=top data-html=true` contact sensor is present) and that the gasket is in good condition and properly seated.
2. Check that the 2 round magnets that hold the pellet tank door are in good condition and that nothing is caught on them (which could block the door from closing properly).
3. Check that the ash pan door is properly closed and locked.
4. Check that the air intake at the back of the stove is not obstructed.
5. Hold down the `data-toggle=tooltip data-placement=top data-html=true` ignition button on the remote control until the text Final cleaning appears.
6. Wait about 10 minutes until the stove has completed its cleaning cycle
7. Clean the unit: empty the ashes, clean the brazier and vacuum
8. As soon as Off appears on the remote control, you can restart the stove

## If the above solution does not work:

The pressure switch does not detect the correct pressure when operating the heater, this may indicate that a fireplace element has opened/not closed completely or it may also indicate that the flue pipe is clogged. Have your local chimney sweep check or clean your flue.